
























































# Cable Connector Guide

 <b>HDMI</b> Digital Video and Audio	 <b>DVI-I Dual Link</b> Digital or Analog Video	 <b>DVI-I Single Link</b> Digital or Analog Video	 <b>DVI-D Dual Link</b> Digital Video	 <b>DVI-D Single Link</b> Digital Video
 <b>DVI-A</b> Analog Video	 <b>DFP</b>	 <b>VGA</b>	 <b>External Power</b>	 <b>HDI30</b> Apple's PowerBook
 <b>Mini3</b> AppleTalk & LocalTalk	 <b>Mini4</b> Apple's ADB Port for Mouse & Keyboard	 <b>Din5</b> PC Keyboard & AppleIIC Serial	 <b>Mini6</b> PS/2 Keyboard & Mouse	 <b>Mini8</b> Image/Laser Writer & Serial Printers, HP DeskWriters
 <b>Mini9</b> Bus Mouse	 <b>BNC</b> Networking	 <b>Twinax</b> Networking	 <b>TNC</b> Networking	 <b>F-Type Coax</b> Networking
 <b>N-Type Coax</b> Networking	 <b>RJ45</b> 8 Wires Network	 <b>13W3</b> Sun Workstation	 <b>DB9</b> Serial Mouse & Printer, Mono Monitor	 <b>HD15</b> VGA & SVGA
 <b>DB15</b> Joystick, AUI, Mac Video	 <b>DB25</b> PC Serial or Parallel IEEE1284 Type A	 <b>DB37</b> Serial, CD-Rom, Bernoulli Box	 <b>DB50</b> SCSI I	 <b>HPDB50</b> SCSI II
 <b>HPDB68</b> SCSI III	 <b>Centronic 24</b> IEEE488	 <b>Centronic 36</b> Parallel & IEEE1284 Type B	 <b>Centronic 50</b> SCSI I	 <b>HPCen36</b> IEEE1284 Parallel Type C
 <b>HPCen50</b> SCSI & Think Pad SCSI	 <b>HPCen60</b> RS/6000 & Think Pad SCSI	 <b>HPCen68</b> RS/6000	 <b>.8mm VHDCen68</b> UltraSCSI	 <b>IDC34 Edge Card</b> Internal 5.25 Floppy & Tape
 <b>IDC34 Socket</b> Internal 3.5 Floppy & Tape	 <b>IDC40 Socket</b> Internal IDE HD, CD ROM	 <b>IDC50 Header</b> Internal SCSI Drives	 <b>1394 4Pin</b> Firewire	 <b>1394 6Pin</b> Firewire
 <b>ST Connectors</b> Fiber Optics	 <b>USB A</b>	 <b>USB B</b>	 <b>Mini USB A</b>	 <b>Mini USB B</b>
Note: Pictures of cable connectors are not proportional.	 <b>Internal Power</b>	 <b>Small Internal Power</b>	 <b>Hooded External Power</b>	Note: Pictures of cable connectors are not proportional.

## Wired New Zealand Limited

Unit B, 2 Centennial Highway, Ngauranga, Wellington

Ph: 04 499 4110, Fax: 04-499 4114

email: [sales@wirednz.co.nz](mailto:sales@wirednz.co.nz)

[www.wirednz.co.nz](http://www.wirednz.co.nz)